

PROTECTING PROFESSIONALS FROM POTENTIAL FENTANYL EXPOSURE.



First Defense™ Wipes provide a safe, fast, and convenient way to detect potential fentanyl on surfaces, helping reduce harm to professionals who may be exposed to this dangerous substance.

These easy-to-use wipes are designed for professional use only and are a key tool for risk mitigation.

WHY CHOOSE FIRST DEFENSE™ WIPES?

SAFE: Formulated with plant-based technology and environmentally friendly ingredients.

FAST: Delivers presumptive results quickly with a clear color-change indicator.

CONVENIENT: Single-use wipes packaged for portability and instant results.

EFFECTIVE: Helps professionals take preventive steps to reduce exposure risks.

DIRECTIONS FOR USE



1. PROTECT YOURSELF: Put on nitrile exam gloves.



2. PREPARE: Open a single-use wipe. Use immediately.



3. TEST THE SURFACE: Wipe the suspected area thoroughly.



4. CHECK RESULTS: Observe for a color-change indicator if fentanyl is present.



5. DISPOSE SAFELY: Follow your department's disposal protocol.



6. CLEAN UP: Wash hands with soap and warm water.

PACKAGING OPTIONS

- Sleeve = 25 wipes
- Box = 100 wipes (4 sleeves)
- Case = 1,000 wipes (10 boxes)



PRODUCT DETAILS

- **Warnings:** Not for use on human skin or diagnosing medical conditions. Not intended for testing trace evidence on skin. Causes serious eye irritation. IF IN EYES: Rinse cautiously with water for several minutes. If eye irritation persists, get medical advice/attention.
- **Disclaimer:** First Defense™ is a risk mitigation tool, not a drug test. Due to the variations and constantly changing nature of available street drugs, wipes may yield rare false positives and false negatives. Use responsibly: always wear nitrile exam gloves. For harm-reduction and awareness purposes only. Do not treat as a definitive test.
- **Ingredients:** Utilizes plant-based technology.
- **Storage:** Keep cool, out of direct sunlight, and away from ignition sources.



LEARN MORE



DISTRIBUTED BY:

Veterans Medical Distributors
office@vmdinc.com
561-588-3222

MANUFACTURED FOR: VISUAL DETECTION SYSTEMS,
310 SOUTH GRANT STREET, MINERVA, OHIO 44657

VDS
VISUAL DETECTION SYSTEMS™